

### **USER MANUAL**

# \_07

bas

20:21 February 4, Friday

-

6° :: Humidity: 82% Temperature: 22,2 C Wind: 1,9 km/h

20:11 February 4, Friday 6° 🔅

Obas P


Humidity: 82% Temperature: 6°C Wind: 1,9 km/h

Messages 0 Cameras

**IP INDOOR VIDEO ENTRY PHONE** 

Outdoor panels





### Main features

- **Display:** 7" IPS LCD, capacitive touchscreen.
- Screen resolution: 1024 × 600.
- Built-in camera: No.
- Power: PoE and + 12 V DC (PSU not included).
- Power consumption: 6 W, standby 2.5 W.
- Dimensions: 195 x 127 x 27 mm.
- Colors: Black, White.
- Body: Plastic.
- Installation Type: Wall mount.
- Mounting options: Horizontal and vertical.

### IP INDOOR VIDEO ENTRY PHONE






Full User Manual wiki.bas-ip.com

### **Device description**

7" IP video indoor monitor with overhead horizontal and vertical mounting options, the ability to control the lift, display messages from the management company, PoE, connection of 32 cameras, memory for photos / videos and an autoresponder. OS - Android 10.0.

### Appearance



- 1 Unlock button.
- 2 Screen
- 3 Microphone.

### **Completness check of the product**

Before installing the monitor, be sure to check that it is complete and all components are available.

26 EAE C€

#### The monitor kit includes:

Monitor	1pc
Wall mounting bracket	1pc
Manual	1pc
Set of wires with connectors for connection of alarm loops, doorbell and home automation	1pc
Resistors for alarm loops	8 pcs
Installation screws	2 pcs

### **Electrical connection**

After verifying the device's completeness, you can switch to the monitor connection.


### To connect monitor you will need:

 An Ethernet UTP CAT5 or higher cable connected to a PoE switch or to a normal switch/router.

**Cable length recommendations** The maximum length of the UTP CAT5 cable segment shouldnot exceed 100 meters, according to the IEEE 802.3 standard.


- Power supply at +12 Volts DC if there isn't PoE.
- Wires must be brought for the connection of alarm loops and home automation (optional).






Using the siren output as a controlled output, to control devices or any other external load with high current consumption






Wiring diagram using various types of buttons connected to alarm loops, and using them as a «Call Button»





Wiring diagram for security alarm sensors with NC normally closed contact types



# ¥ EAE C€



### Appearance and mechanical mounting


Before installing the monitor, a hole must be drilled in the wall to fit the standard mounting box with the monitor bracket mounting dimensions of 60 mm between the two mounting screws.


The standard mounting box can be installed either round with dimensions of  $65 \times 45$  mm (2.56x2.13 inches) or quadrant type with dimensions of  $86 \times 86 \times 45$  mm. The mounting box under the monitor bracket is required for wiring connections and securing the monitor bracket itself.

The hole should be made at a height of 150-160 cm from the floor.

Attach the bracket in the outlet box using set screws and a phillips head screwdriver. Installation of the monitor on the bracket is done from top to bottom.

### Vertical mounting






**Surface bracket** Screw holes strictly at 90° and fasteners as shown in the schematic image

### Fixation

Set monitor at an angle and twist it until it clicks

Niche 150-160 cm from the floor








Niche 150-160 cm from the floor



### Horizontal mounting







**Surface bracket** Screw holes strictly at 90° and fasteners as shown in the schematic image

**Fixation** Set monitor at an angle and twist it until it clicks

## ¥¥ [A[ C€

### Warranty

The warranty card number Model name Serial number Seller name

With following stated terms of warranty is familiar, functional test was performed in my presence:

Customer signature

### Warranty conditions

### The warranty period of the product -36 (thirty-six) months from the date of sale.

- Transportation of product must be in its original packaging or supplied one by the seller.
- The product is accepted in warranty repair only with a properly filled warranty card and the presence of intact stickers or labels.
- The product is accepted for examination in accordance with the cases provided by law, only in the original packaging, in a full complete set, appearance corresponding to the new equipment and presence of all relevant properly filled documents.
- This warranty is in addition to the constitutional and other consumer rights and in no way restrict them.

### Terms of warranty

- The warranty card must indicate the name of the model, serial number, purchase date, name of the seller, seller company stamp and the customer's signature.
- Delivery to the warranty repair is carried out by the buyer himself.
- Warranty repairs carried out only during the warranty period specified in the warranty card.
- The service center is committed to do everything possible to carry out the repair warranty products, up to 24 working days. The period spent on the restoration of product functionality is added to the warranty period.



Notes




Notes





www.bas-ip.com